





MODEL	UB 5220 PH	
Nozzle	ABS	
Control	Side panel	
WASH FUNCTION		
Cleansing	Press "Cleansing" to clean your posterior	yes
	Function will stop 60 sec automatically	
	Press again to activate oscillation	
Bidet	Press "Bidet" for feminine wash	yes
	Function will stop 60 sec automatically	
	Press again to activate oscillation	
HYGIENE FUNCTION		
Dry	Press "Dry" after cleansing or bidet function	yes
	Far infrared ray type of warm air will activate for 3 min	
	Press again to adjust the air pressure	
Air	Press "Air" to dry	yes
Self Cleaning	The unit keeps its nozzle clean automatically before	yes
	and after use by rinsing it off.	
CONVENIENCE FUNCTION		
Massage	Press "Pulsation" to activate rhytmical wash for massage effect	yes
Kids	Press "Kids" to change all function to be suitable for children	yes
	1 minute oscillation, 3 minutes dry	
	Level 1 water pressure	
Auto	Press "Auto" during the operation of cleansing: cleaning wash,	yes
	oscillating wash and dry will operate for 20 sec each consecutively	
LED	LEDs are illuminated with washing, bidet, drying, massage, etc.	yes
Nozzle position	Adjustable nozzle position	yes
SAFETY FUNCTION		
Seat sensor		yes
ELCB		yes
Thermostat Fuse		yes
Heating seat		yes
Soft close		yes





